


MEASURING A TYPICAL HINGED DOUBLE DOOR FOR THE NET SCREEN OPENING DIMENSIONS

Begin by deciding where best to position the screen. **The opening must be plumb, level and square and, the bottom guide of the retractable screen must rest on a flat, level and solid surface.** Make any needed adjustments to the opening (or plan and allow for shimming) before measuring for the screen. Determine the "NET SCREEN OPENING DIMENSION" (width x height) as measured from where the outside most edges of the retractable screen will rest. Screens are then made to fit these dimensions. Manufacturing tolerances are plus or minus 1/16". We recommend that with inside the frame installations (options A or B) that you deduct an additional 1/16" in the width and height dimensions that you submit in order to assure that the screen is not too tight in the opening during installation. If you plan on using shims or threshold transitions then be sure to also deduct appropriately for these.



COMMON INSTALLATIONS

- OPTION A** Inside the Frame (Recess/Inset Mounted)
- OPTION B** Fully Inside the Frame (Recess/Inset Mounted)
- OPTION C** Outside the Frame (Surface/Face Mounted)

RECORD FINAL NET SCREEN



OPENING DIMENSIONS

W _____



H _____

(If using installation option A or B, deduct 1/16" from the width and height to order).



OPTION A (Recommended) INSIDE THE FRAME INSTALLATION (Recess Mounted) at the Brick Mold



OPTION B INSIDE THE FRAME INSTALLATION Fully Inside the Master Frame



OPTION C OUTSIDE THE FRAME INSTALLATION (Surface/Face Mounted)



For sliding patio doors, terrace doors and other openings, please contact us for additional guidance.